



General Maintenance

- ◇ Periodically check that all bolts and nuts are tight. Through constant wind and wave action, nuts can work themselves loose. AccuDock suggests this to be done once per year, or upon visual notice.
- ◇ Keeping the surface clean will lengthen the life of your AccuDock. When dirt accumulates on the surface it will attract the sun's rays at a higher level. This will dry out the plastic at a faster rate than if the dock is kept clean. AccuDock suggests washing the surface with a pressure washer or washing broom with soap at least twice per year.
- ◇ Bottom paint can be put on the underside of your floating dock prior to installation, however it will need to be re-applied every couple of months. Anything that is left in the water will accumulate growth, which can be easily scraped off with a flat edge or paint scraper. If your AccuDock is seasonal and taken out of the water each year, up to a 3500 PSI pressure washer can be used to clean the growth.
- ◇ Some items will have rope/line that will need to be attended to that could fray over time. Examples of these items are, but not limited to, Safe Launches, SlideMoors or Fenders.

FOR QUESTIONS OR MORE INFORMATION CALL 954.785.7557 OR
EMAIL SALES@ACCUDOCK.COM

WWW.ACCUDOCK.COM